

## **ATA TX4A GREEN BUTTON REMOTES CODING 27MHZ HOPPING CODE**

1. Press and hold door code button on the opener.
2. Press the remotes button you would like to use to control the door for 2 seconds.
3. Release and pause for 2 seconds. Press the same button again for 2 seconds then release.
4. Release the door code button.
5. Press the remote button to test operation.